




# COVoice and COVoice Express PMS Setup




## DIRECT CONNECT

Note: Null Modem Adapter may be required on RS-232 link between COVoice and PMS systems



## DIRECT CONNECT VIA 2 SERIAL PORT FROM THE PROPERTY MANAGEMENT SYSTEM

Note: Null Modem Adapter may be required on RS-232 link between COVoice and PMS systems



## MONITOR MODE

COVoice/COVoice Express uses Data Tap to monitor PMS protocol